

# INSTALLATION GUIDE

## CREATON UNI safety hook, type 1



Place the supporting steel beam to the correct position. You can find the distance of the beam in the end of this guide. The beam has 50x30x2x1200 mm dimensions.



Use the 2 pcs of 6x140 torx headed screws to fix the beam!



Place the safety hook to the beam according to the covering method because you have to put a ventilation tile above the support!



Use the 2 pcs of the 4,8x38 hexagonal head steel self screw bolts to fix the supports!



Finish the tile cover and use the ventilation tiles above the safety hook!



For some tile model you have to broke out one or more support in the ventilation tiles! You can find further information about this in the end of this guide!

A notice:

- The specifications of national regulations (such as ZVDH, ÖNORM or SIA standards) as well as national and European standards (such as DIN or EN) must be kept.
- The installer is responsible for the processing and installation of the products in accordance with the assembly instructions and the resulting tightness in the sub-roof.
- CREATON South-East Europe Kft. has no responsibility for damage caused by improper installation.

## Guide for the different tile mode

Model	Type number	Dist. of the steel beam	Ventilation tile break out
<b>Domino</b>	<b>1</b>	<b>150 mm</b>	<b>yes</b>
<b>Cantus</b>	<b>1</b>	<b>140 mm</b>	<b>yes</b>
<b>Ratio</b>	<b>1</b>	<b>150 mm</b>	<b>yes</b>
<b>Simpla</b>	<b>1</b>	<b>145 mm</b>	<b>yes</b>
<b>Maxima</b>	<b>1</b>	<b>150 mm</b>	<b>nem</b>
Rapido	2	175 mm	no
Balance	3	230 mm	no
Nomina	3	230 mm	no
Magnum	3	230 mm	no
Premion	3	230 mm	no
Futura	3	230 mm	no
Optima	3	230 mm	yes
Sinfonie	3	230 mm	yes
Melodie	3	230 mm	no
Titania	3	230 mm	yes
Klassik 18x38	4	-	-
Klassik 20x40	4	-	-
Ambiente 18x38	4	-	-
Ambiente 20x40	4	-	-
Róna szegment cut	4	-	-
Róna straight cut	4	-	-
Hortobágy	4	-	-
Heidelberg	5	150 mm	-
Göteborg	5	150 mm	-
Kapstadt	5	150 mm	-

